

Cornice Installation Guide

Tools Required

Small Angle Grinder

1mm aluminium grinding disc

Scriber

Tin Snips

Clamp

Beeswax or candle for lubricating disc

CAUTION SHOULD BE USED AT ALL TIMES AS METAL EDGES ARE VERY SHARP.

Installation

 Begin with the Cornice Mounting strip. Glue and fix into place along a level line, marked at correct height for your cornice. Lip is to face out.



2. Slip Cornice into the Mounting Strip.



- 3. Affix the top flat cornice edge into your ceiling with nails, tacks etc.
- 4. Sheeting goes over the top edge and butts up ready to fix in place. Sheeting can start from the centre of the room or the cornice edge.



NOTE: There is no need to remove old Cornices unless the old is larger than the new. In some cases, that a batten will be needed to be fitted. Place batten correct width from the wall directly onto the ceiling, so the back of the cornice sits against it. This is to push cornice against to prevent any distortion.

Mitring Cornices

1. Scribe at 45° in nominated position, holding scriber flat to end plate.



2. Clamp to hold in place prior to cutting, cut to the outer side of line.



3. De-burr any sharp edges.



4. Left hand Cornice piece remains "square", to be installed as is. Right hand cornice has been mitred and scribed to fit profile of the left piece.



5. Bring Cornices together, as they will be when installed. Minor trimming may be required to perfect the join.



6. Finished Mitred cornice in place.



7. Install the next length of Cornice into the Mounting Strip, overlapping the previous Cornice. Paintable No-more Gaps may be smoothed over the joins to help them appear seamless.



All instructions given as a guide only. Pressed Tin Panels® will not be held responsible for misuse of instructions. Products are only recommended to affix to ply wood or battens. All instructions are designed for our products only. For all Cornice profiles please refer to web site. All sheet sizes quoted are estimates only. Surface scratches may be present.