# Quick Start Guide Node



### 1) MOUNT

Mount the device firmly to your chosen location using a secure mounting method: Twosided adhesive, side mounting holes and/or pole mount bracket for threaded holes.

## 2) USING THE MAGNET

Wherever instructed to hold the magnet in place, do so at the centre of the 'O' in the Viotel logo.

- Count the number of LED blinks to the desired command.
- 1 LED blink corresponds to 1 second.
- Release the magnet from the hold position will end the command input.

# 3) CONFIRM STATUS

#### 1 LED Blink

- If the device is off, a solid blue light will appear from the status LED. Proceed to step 4.
- If the device is on, a solid green light followed by a red light will appear from the status LED. Proceed to step 5.

## 4) TOGGLE DEVICE ON/OFF

- 4 LED Blinks
- This will turn the device on/off.
- Confirm the device is setup using myViotel. Note: battery consumption varies between continuous and triggered modes.

# 5) VIEW DATA

Please head over to your nodes Dashboard to begin seeing the data.

Please refer to the User Manual for more information and a full guide on this device.

STATUS	
GREEN	On
BLUE	Off
RED	Device is busy
PURPLE	Confirming Command

COMMS	
BLUE	Communicating with server
YELLOW	Collecting GPS Coordinates
RED	Unable to Communicate





## **OUR RESONANCE**

Resonance describes the phenomenon of increased amplitude that occurs when a an external force or a vibrating system is equal or close to a natural frequency of the system on which it acts.

Leveraging decades of experience in earthquake analysis and monitoring of mining seismicity, Viotel have a deep understanding of resonance and have developed a unique series of asset management solutions involving monitoring and analysis of vibrations and waveforms.



The Viotel Wireless Accelerometer Node is an ultra-low noise triaxial MEMS sensor and self-contained with a digital communication interface.

It comes pre-programmed and ready to mount in the desired location and is suitable to measure the vibration modes in buildings.

> www.viotel.co sales@viotel.co

